

Get Started

To turn the game ON, **Pull It!**

Pull It until you hear the name of the game you want to play: **SOLO**, **PASS IT**, or **ONE-ON-ONE**.

Next, **Flick It** to select the mode you want to play in: **VOX BOP** (with voice commands), or **BEAT BOP** (with musical commands).

Note: If you do not **Flick It**, the game will default to the **VOX BOP** mode or the last mode played.

To begin the game you selected, hit the **Bop It** button.



Rules for VOX BOP games (VOICE COMMANDS)

Vox Bop Solo

For 1 or More Players

(if more than 1 player, take turns)

Object: Keep up with BOP IT EXTREME 2 to rack up the highest personal score. Play alone and go for your personal best, or take turns and see who can score highest.

Play: Press the **Bop It** button to start the game. Respond in time to the voice commands. Every time you respond correctly, you score 1 point. If you're too slow, or you respond incorrectly, BOP IT EXTREME 2 will end the game! After every 16 points you score, be prepared for the music style to change! There are four different music styles to play to. Once you get through them all, the tempo will speed up. So be on your toes! Listen carefully to hear your score at the end of the game. Next time, try to beat it!

Winning: In a 2 or more player SOLO game, the winner is the player with the highest personal score.

Vox Bop Pass It

For 2 or More Players

Object: Keep up with BOP IT EXTREME 2, and be the last player "alive".

Play: Face the other players in a circle. Choose a player to go first. Press the **Bop It** button to start the game. Respond in time to the voice commands. When you hear "Pass It", quickly hand the game to the player on your left. If you don't respond in time or you respond incorrectly to the command, you're out of the game! The player to your left continues the game by pressing the **Bop It** button.

Winning: If you're the last player left, you win but only if you can survive a final sequence (until you hear "Pass It")!

Vox Bop One-On-One

For 2 Players

Object: Keep up with BOP IT EXTREME 2, and be the first to score 5 points by responding to the voice commands correctly and beating the other player to the **Bop It** button.

Play: Each player grabs one handle, and is assigned a colour: yellow or green. The yellow player is responsible for **Twist It**, **Pull It**, and the side of the **Bop It** with screws. The green player is responsible for **Flick It**, **Spin It**, and the side of the **Bop It** without screws.



You may not reach across to perform another player's action during the game.

Each player must respond correctly and on time to the voice commands. When "Bop It" is called out, race to hit your colour **Bop It** button.

The game will announce which player hit the button first, and they score 1 point. Be ready to respond to the next command!

If you don't respond correctly or on time to the commands, you're out of the game!

Winning: You win the game if your opponent doesn't respond correctly or on time, or if you're the first to score 5 points! The game will announce which player won.

BEAT BOP GAMES (MUSICAL COMMANDS)

Beat Bop games play the same as VOX BOP games, except your commands are musical!

- A "bass drum" sound means "Bop It".
- A "low-pitched ratchet" sound means "Twist It".
- An "upwards whistle" sound means "Pull It".
- A "wobbling wheel" sound means "Spin It".
- A "boing" sound means "Flick It".



HIGH SCORE

While in the Game Select mode, **Twist It** to hear the Solo game High Score!

VOLUME CONTROL

While in Game Select mode, **Spin It** to set the volume to low, medium, or high.

USING HEADPHONES

For an enhanced personal play experience, try playing with headphones!

First, set the BOP IT EXTREME 2 volume setting on low with the **Spin It** wheel. Next, plug in your headphones to the output jack located under the **Twist It** knob. (You may need to buy an adaptor if your headphone plug does not fit into the jack.) Be careful to avoid the wire, and be mindful of your surroundings as you play.

BLAST IT! CRANK IT! PLAY IT LOUD!

For the ultimate party experience, plug BOP IT EXTREME 2 into your home stereo or amplified computer speakers. Here's how:

First, **Spin It** to set the volume on low. Then plug the game into your computer speakers or using the appropriate audio cable (not included), hook up from your game's headphone jack to any input jack in your home stereo. Set all volume levels at their lowest - then turn them up after the sound starts coming through your speakers!

During a **Pass It** game, players should rotate around the game instead of passing it, to avoid tangling the audio cable.




Assembly

Insert batteries: Loosen the screw on the battery compartment and remove the door. Insert 3 x LR6 AA batteries (we recommend alkaline), making sure to align the + and - symbols with the markings in the plastic. Then replace the door and tighten the screw.

When to change the batteries: If BOP IT EXTREME 2 doesn't "wake up" or the game performance changes, try reinserting the batteries. If that doesn't work, remove the old batteries, then insert three new batteries.

Object

Keep up with BOP IT EXTREME 2! Here's how: BOP IT EXTREME 2 will command you to do these five things... in random order!



Respond as quickly as you can! If you respond correctly, BOP IT EXTREME 2 will quickly give you the next command. But if you're not quick enough, or you respond incorrectly, you're out!

IMPORTANT BATTERY INFORMATION:

BATTERIES MUST BE REPLACED BY AN ADULT. PLEASE RETAIN THIS INFORMATION FOR FUTURE REFERENCE.

CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short-circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. RECHARGEABLE BATTERIES: Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERY.



This product and its batteries must be disposed of separately at your local waste recycling centre. Do not dispose of them in your household waste bin.

© 2011 Hasbro. All rights reserved.
 Manufactured by: Hasbro SA, Route de Courmou 6, 2800 Delémont, CH
 Represented by: Hasbro Europe, 2 Roundwood Ave, Stockley Park, Uxbridge, Middlesex, UB11 1AZ, UK
 Hasbro Australia Ltd., Level 2, 97-41 Oxford Street, Epping NSW 2121, Australia.
 Tel: 1 800 138 697. Hasbro NZ (a branch of Hasbro Australia Ltd.), 221 Albany Highway, Auckland, New Zealand. Tel: 0508 828 200.
 Consumer Services: Hasbro UK Ltd., PO Box 43 Newport NP19 4YD, UK.
 Tel 0200 22427276. Consumer: affairs@hasbro.co.uk

www.hasbro.co.uk



051168887102 01



danger!
 quick to play
 and seriously
 addictive

BOP it Extreme 2

totally hands on!



AGE
8+



1+
 PLAYERS

x3 LR6 AA Batteries
 NOT INCLUDED
BATTERIES REQUIRED
 Alkaline batteries recommended. Rechargeable
 NiMH or NiCd batteries (not included) need to
 be used with a separate recharger.

**MB
 GAMES**